
STANDING CIRCULATION FAN

INSTRUCTION MANUAL



Model:KCF-10SRD

Please read the instructions carefully before using this product.


PRODUCT PARAMETERS

Product name:	Standing Circulation Fan
Model:	KCF-10SRD C24V
Adapter:	1A
Motor :	DC Motor
Rated power:	24W
Product size :	330X330X925mm
Net weight:	2.3kg
Packing list:	Fan head x1 Support tubes x 2 Base x 1
	Remote control x1、User manual x1、Power adapter x1

POWER ADAPTER SPECIFICATION

Input data :	AC100-240V , 50/60Hz
Output date :	DC24V , 1A


WIRING DIAGRAM




PERFORMANCE


- The height of the fan can be adjusted by using different combinations of Support tubes found in this package. It can be used as standing fan or desktop fan suitable for offices, homes, dormitories, etc.
- Timer setting from 1 to 8 hours.
- Adjustable wind speed from 1 to 9 grades.
- Remote control operation, more comfortable to use.
- Wide-angle air supply. The oscillation angle can reach 120° while the tilting head up to 100%.

PRODUCT SIZE



MAIN PARTS







INSTALLATION

Notice: Do not insert the adapter output plug into the body when assembling the fan.

- 1. Install Support tube 1 into hole of the base, and install Support tube 2 into corresponding hole of Support tube 1,then install the combined part into the top body, rotate clockwise until all parts are tightened. (Refer to Figure 1)
- 2. The Support tube can be disassembled, just connect the top body to the base, and it can be used as desktop fan. (Refer to Figure 2)






USE GUIDE

- After assembling the fan components according to installation requirements, place the fan on a smooth ground or table top, insert the power adapter output plug (DC24V 1A) into the power input port at the bottom of the fan head, and then insert the adapter input plug into the household power socket.
- After the preparation, the fan can be controlled by the touch switch on the control panel, or the remote control can be used to control the operation. (Before using the remote control, remove the battery isolation strip at the end of the remote control)

OPERATING INSTRUCTION



1. On/off

After the plugging in of the unit, press the On/Off button!" \bigcirc " in standby state, and the fan enters I speed working mode. Press the On/Off button again, and the machine enters standby state.

2. Wind speed adjustment

After the switching on of the fan, touch the wind speed button \(\&\) " lightly, the wind speed will increase by 1 speed according to the current speed every time. If wind speed is adjusted to 9 speed, press the wind speed button again and the gear will continue to circulate from 1 speed.

3. Timer setting

After the turning on of the fan, press the timer button " in the control panel.

Press the timer button consecutively to set the time of operation from 1 hour up to 8 hours. To remove timer, press the timer button until "0h" appears.

4. Oscillation setting

When the fan is running, tap the oscillation button " " to enable the oscillation function. The angle of oscillation is 60 degrees. Tapping the button continuously, the angle of oscillation will be increased to 90 degrees and 120 degrees successively until the oscillation function is closed.

5. Tilt setting

When the fan is running, tap the tilt oscillation button " $\langle \cdot \rangle$ " to enable the fan tilt oscillation function. The fan tilt angle is 100°. Tap the tilt oscillation button again to turn off the tilt oscillation function.

COMPONENT DISASSEMBLY INSTRUCTION

FRONT HOUSING DISSASSEMBLING

- 1 Turn the phillips screwdriver counterclockwise to remove the outlet housing screw
- 2 Rotate the outlet housing counterclockwise to unlock
- 3 Remove the outlet housing










BLADE DISASSEMBLING

4 Rotate clockwise to release blade lock

5 Draw blade forward to remove blade







REAR HOUSING DISASSEMBLING

- 6 Turn the phillips screwdriver counterclockwise to remove the inlet housing screw
- **7** Rotate the inlet housing counterclockwise to unlock
- 8 Remove the inlet housing







riangle NOTES :

- ⚠ Please use the power adapter provided with the product. Before use, please make sure that the input voltage is used as required by the adapter within the voltage range (Adapter input: AC100-240V, 50/60Hz; output: DC24V, 1A).
- The user is not allowed to disassemble and replace the internal parts of the fan at will. If there is any fault, please contact the after-sales service department for repair.
- Product features and specification are subject for change without prior inotice.
- ⚠ If the appearance and color of the product are changed, please refer to the actual product.
- Avoid aiming directly to babies and elderly for a long time as the product wind is strong
- Mhen the power cord or product is found to be damaged or unsafe, please suspend the use. Contact the Authorized Service Center or its after-sales service agents to replace the product. Do not repair and check by yourself.
- Children, elderly or patients who have lost the ability to take care of themselves should use this product under adult supervision to prevent accidents.
- This product should be placed out of reach of children, and the children should be taught correctly. Do not use this product as a toy.
- ⚠ In order to avoid electric shock, no part should be in contact with water.
- ↑ There can be no objects blocking the air inlet/outlet.
- Please use this product in an environment of 0~40°C. <u>Don't put the fan in</u> the bathroom, humid or very high temperature place, to avoid damaging the product.
- ⚠ Please keep the fan away from soft objects such as curtains and door curtains to avoid getting caught in the fan.
- ⚠ Please unplug the power plug before cleaning or moving the product.
- Mhen the fan is not used for a long time, please unplug the power plug to prevent the product from shortening the product life and causing accidents or dangers in the standby state for a long time.

- ⚠ Do not put fingers, other body parts or debris into the air inlet/outlet to avoid injury and damage to the product.
- ⚠ When removing the protective shell for cleaning, be careful not to touch the touch buttons to avoid accidents in the operation of the product.



Please do not throw this product away with other household waste. When it is no longer used, the product must be sent to the appropriate department for recovery and recycling.

If you place electrical appliances in a landfill or garbage dump, harmful substances may seep into the groundwater, enter the food chain and harm your health and life.

CLEANING MAINTENANCE AND SAFETY MATTERS

- 1. When cleaning, maintaining or moving the product, you must first turn off the product and then unplug the power cord.
- 2. The fan must be completely stopped before it can be cleaned to avoid injury.
- 3. Do not immerse the power cord or main unit in water for cleaning or wash it under a faucet. The internal parts of the fan must not be wetted.
- 4. Do not use detergent, wire brush, gasoline, alcohol, vinegar or other volatile corrosive liquids to clean the product to avoid damage to the product.
- 5. Clean the surface of the fan with a slightly damp cloth.
- 6. After cleaning, the product must be complete dry before it can be connected to the power supply
- 7. If you will not use it for a long time, please store the product back in the box and store it in a dry, cool and safe place.

6. After cleaning, the product must be completely dry before it can be connected to the power supply.

	se it for a long time, please y, cool an 6Aಟ್SE place. ANALYSIS	store the product back in the box TREATMENT MEASURES
gently squeeze the	water was a water	t cotton գա կց ի րե իթ քերգև ներ, and absorbei PP Vott6P ԳԻ ՍՍԵՐ and
ventil å⁄led hø la ce, le sheet ^c ββ¦tt₩9tK a s	et it dry naturally and store oft brush.	or use it again: clean the atomized
9. When cleaning	The switch button is the outer Strace of the hu	Press the switch midifier, all the few the far blades
deter gent ralag the sound	n wipevitneviteracceotengamp Motor damage.	ened withRitplace the fan blades. Replace the motor.

The design and specifications are subject to change without prior notice for product improvement. Any updates to the manual will be uploaded to the service website, please check for the latest version.

If you have any concerns, please contact us at the following:

Customer hotline: (02) 8852-6868 Text hotline: +63 917-881-8982

Email: customerservice@kolinphil.com.ph

Also, please like and follow us on our social media accounts:

Facebook: kolinphilippines Instagram kolinphilippines Youtube: kolinphilippines Tiktok: kolinphilippines

Website: www.kolinphil.com.ph

KOLIN PHILIPPINES INT'L., INC. SERVICE CENTERS

BRANCH	ADDRESS	TEL. NO.	
Bacolod	Door #A-2 & A-3 UTC Bldg., Alunan St., Brgy. Singcang, Bacolod City	(034) 433-0031	
Cagayan De Oro	Door #3 De oro Land Bldg., Julio Pacana St., Puntod, Cagayan De Oro City	(088) 856-4672	
Cebu	Unit #6 A. Geson Bldg., D. Jakosalem cor. F. Ramos St., Cebu City	(032) 253-9997 / (032) 253-7944	
Dagupan	Unit #1107 Caranglaan District, Dagupan City Pangasinan	(075) 523-2832	
Davao	Blk 17 Lot 9, Calamansi St., Juna Subd., Matina, Davao City	(082) 227 - 7063	
lloilo	Door #4 D' Appliance Arcade, South Fundidor, Moli, Iloilo City	(033) 336-1970	
Pampanga	LRK Commercial Bldg., Jose Abad Ave., Lagundi Mexico, Pampanga	(045) 455-2934	

For More air conditioner tips, please like, share and follow us on our social media accounts:

Facebook: kolinphilippines Instagram: kolinphilippines Youtube: kolinphilippines kolinphilippines Tiktok:

www.kolinphil.com.ph Website:

OFFICE

Kolin Bldg., 1854 Sta. Rita St., Guadalupe Nuevo, Makati City Service Hotline: (02) 8852-6868

PLANT

Blk 3 Lot 5, Main Drive First Cavite Industrial Estate, Langkaan 1, Dasmariñas City, Cavite Tel. No.: (046) 402-0793